



RIW Sheetseal 226:  
see Notes 3 & 4

Concrete blinding

RIW Sheetseal 226:  
to seal top of RIW  
Double Drain against  
vertical membrane

RIW Double Drain:  
see Notes 1 & 2

RIW Flexiseal Pro

- Notes:
1. Double Drain relieves hydrostatic pressure build up, and provides an additional factor of safety. However, if site conditions allow, Protection Board may be used instead.
  2. Double Drain is to be installed with the filter fleece facing outwards towards the soil/ground.
  3. Where the floor membrane is not subjected to hydrostatic pressure, then if preferred, DPM Blue may be used laid on a sand blinding. Consult RIW for lapping /sealing details.
  4. If thought necessary, the horizontal sheet membrane may be covered and protected to reduce the risk of damage from following works.

EXTERNAL VERTICAL TANKING:  
TYPICAL DETAIL AT TOP OF INTERNAL MASONRY RETAINING WALL WITH GROUND BEARING SLAB

|                        |                |
|------------------------|----------------|
| DRAWING NO: RIW/TD/152 | SCALE: NTS     |
| DATE: 14/07/2017       | CHECKED BY: DK |
| DRAWN BY: RA           |                |

