



- Notes:
1. Double Drain relieves hydrostatic pressure build up, and provides an additional factor of safety. However, if site conditions allow, Protection Board may be used instead.
  2. Double Drain is to be installed with the filler fleece facing outwards towards the soil/ground.
  3. Where the floor membrane is not subjected to hydrostatic pressure, then if preferred, DPM Blue may be used laid on a sand blinding. Consult RIW for lapping/sealing details.
  4. If thought necessary, the horizontal sheet membrane may be covered and protected to reduce the risk of damage from following works.

EXTERNAL VERTICAL TANKING: SHEETSEAL 226 CONTINUITY DETAIL  
 TOP OF INTERNAL CONCRETE RETAINING WALL WITH GROUND BEARING SLAB

DRAWING NO:	RIW/TD/154	SCALE:	NTS
DATE:	14/07/2017	CHECKED BY:	DK
DRAWN BY:	RA		

