



- Notes:
1. Double Drain relieves hydrostatic pressure build up, and provides an additional factor of safety. However, if site conditions allow, Protection Board may be used instead.
 2. Double Drain is to be installed with the filter fleece facing outwards towards the soil/ground.
 3. A maintainable sub-soil drainage must be provided at the base of the wall.
 4. Sub-soil drainage should be capable of discharging water away from the structure.
 5. RIW Brick Plugs fix the RIW Cavity Drain to wall and allow for screw in type wall-ties.

DRAWING NO: RIW/TD/211	
DATE: 22/09/2017	SCALE: NTS
DRAWN BY: RA	CHECKED BY: DK



SUSPENDED FLOOR:
 HABITABLE SPACE WITH FLOOR LEVEL GREATER THAN
 600MM BELOW EXTERNAL GROUND LEVEL