



- Notes:
1. Double Drain relieves hydrostatic pressure build up, and provides an additional factor of safety. However, if site conditions allow, Protection Board may be used instead.
  2. Double Drain is to be installed with the filter fleece facing outwards towards the soil/ground.
  3. A maintainable sub-soil drainage must be provided at the base of the wall as required.
  4. Sub-soil drainage should be capable of discharging water away from the structure.
  5. RIW Flexiseal Pro is applied to the outside of the wall, to limit water ingress into the cavity.
  6. Wall ties must not be allowed to puncture the membrane.

- Provide weepholes as required, 40mm minimum to avoid blockages
- Provide ventilation to sub-floor void as required



SUSPENDED FLOOR:  
 HABITABLE SPACE WITH FLOOR LEVEL LESS THAN 600MM  
 BELOW EXTERNAL GROUND LEVEL

DRAWING NO: RIW/TD/212	
DATE: 22/09/2017	SCALE: NTS
DRAWN BY: RA	CHECKED BY: DK