



LAC, Flexiseal Pro,
Heviseal, or
Toughseal

Sheetseal 226

Structureseal

- Notes:
1. DPM Red to be turned up at edge of slab, 75 mm minimum.
 2. Do not apply RIW Sheetseal Primer onto applied sheet membranes.



DAMP PROOFING: RIW DPM RED / RIW DPM BLUE SIMILAR
TYPICAL LINKING DETAILS TO OTHER RIW PRODUCTS

DRAWING NO.:	RIW/TD/304	SCALE:	NTS
DATE:	22/09/2017	CHECKED BY:	DK
DRAWN BY:	RA		